
CENTRAL COAST HYDROLOGIC REGION



Some Statistics

- Area 11,326 square miles (7.1 % of State)
- Average annual precipitation 18.7 inches
- Year 2000 population 1,459,205
- 2030 projected population 1,890,390
- Total reservoir storage capacity 1,227 TAF
- 2000 irrigated crop area 603,620 acres

CENTRAL COAST HYDROLOGIC REGION WATER BALANCE SUMMARY - TAF

	Water Year (Percent of Normal Precipitation)		
	1998 (225%)	2000 (110%)	2001 (107%)
Water Entering the Region			
Precipitation	25,202	12,596	11,848
Inflow from Oregon/Mexico	0	0	0
Inflow from Colorado River	0	0	0
Imports from Other Regions	108	144	180
Total	25,310	12,740	12,028
Water Leaving the Region			
Consumptive Use of Applied Water *	622	754	860
(Ag, M&I, Wetlands)			
Outflow to Oregon/Nevada/Mexico	0	0	0
Exports to Other Regions	66	89	133
Statutory Required Outflow to Salt Sink	174	95	49
Additional Outflow to Salt Sink	154	181	183
Evaporation, Evapotranspiration of Native Vegetation, Groundwater Subsurface Outflows, Natural and Incidental Runoff, Ag Effective Precipitation & Other Outflows	24,502	12,362	11,688
Total	25,518	13,481	12,913
Storage Changes in the Region			
[+] Water added to storage			
[-] Water removed from storage			
Change in Surface Reservoir Storage	401	8	-14
Change in Groundwater Storage **	-609	-749	-871
Total	-208	-741	-885

Applied Water * (compare with Consumptive Use)	1.074	1.291	1.442
* Definition - Consumptive use is the amount of applied water used and no longer available as a source of supply. Applied water is greater than consumptive use because it includes consumptive use, reuse, and outflows.	,,	,	,,

Water Entering the Region – Water Leaving the Region = Storage Changes in Region

**Footnote for change in Groundwater Storage

Change in Groundwater Storage is based upon best available information. Basins in the north part of the State (North Coast, San Francisco, Sacramento River and North Lahontan Regions and parts of Central Coast and San Joaquin River Regions) have been modeled – spring 1997 to spring 1998 for the 1998 water year and spring 1999 to spring 2000 for the 2000 water year. All other regions and year 2001 were calculated using the following equation:

GW change in storage =

intentional recharge + deep percolation of applied water + conveyance deep percolation - withdrawals

This equation does not include the unknown factors such as natural recharge and subsurface inflow and outflow.